JennSwing® Replacement Harness Instructions

1. Preparation

- **Layout:** Unpack the replacement harness and lay it flat on a surface to identify the top chest section, middle waist section, and the crotch strap.
- **Disassembly:** Unbuckle each side of the waist straps and detach the crotch strap piece, setting it aside. Unthread the straps from their upper and lower buckles so you are working with clean, unattached webbing.

2. Installing the Crotch Strap

1. Take the strap that goes between the child's legs.
2. Insert it down through the slot closest to the middle of the swing seat, and bring it back up through the front slot.
3. Weave and secure the strap through its plastic adjustment buckle.

3. Installing the Main Harness Webbing

4. Take the main chest/upper harness webbing and thread it through the upper seat slots from front to back, ensuring the straps stay flat and do not twist.
5. Thread the web harness through the chest portion layout.
6. Feed the waist portion of the harness through the middle slots of the seat.

4. Reconnecting and Adjusting Buckles

7. Snap together the buckle on one side of the waist harness.
8. Reattach the short strap through the "rock lobster" style or matching male buckle (*tip:* a flat-head screwdriver can help guide and pull the webbing through tight slots if needed).
9. Snap together the second waist buckle.
10. Adjust the shoulder and waist straps through their respective buckles to ensure a snug, centered, and secure fit for the individual child.

> **Video Guide**
>
> You can visually follow along with these steps by viewing the installation video here: https://www.backyardcity.com/Swing-Set-Accessories/JennSwing-Harness.htm

Safe Use

- **Weight Limits:** Rated for use up to **125 pounds** (JennSwing) and **60 pounds** (Cubby) only.
- **Restrictions:** Not for adult use. Adults must supervise children at all times.

- Do not allow children to stand on the seat or use the swing for any purpose other than its intended design.
- Do not allow it to be used if any part is damaged or worn.

Maintenance

- Perform monthly routine maintenance checks for cracks, rust, open S-hooks, chains, and eyebolts to reduce unnecessary injuries.
- Replace any worn, damaged, or vandalized parts immediately.
- Ensure there are no exposed footings, anchoring devices, rocks, roots, holes, or other obstacles in or around the playground equipment. High-use areas require more frequent inspections.
- Clean the unit with mild soap and water during your monthly maintenance checks.

> **Warranty Notice**
> Any damage resulting from vandalism, abuse, or misuse VOIDS all warranties.