


Water Trellis

Instructions for use



Inspect for shipping damage any damage from shipping should immediately be reported to the delivery agent. Do not attempt to operate if unit is damaged.

Parts List

- | | |
|---|-------------------------|
| Glass Panel (1) | Bag of River Rocks (1) |
| Trellis Upright (1) | FRP Trays for Rocks (2) |
| Base (1) | Bag of Hardware (1) |
| Pump (1) | |
| Rubber Glass Liner (1) <i>For bottom of glass panel</i> | |

Water Trellis Assembly

Please read all instructions before beginning assembly.

- 1 Carefully remove the glass panel, the Trellis Upright and the base from their shipping cartons
- 2 Follow these steps to remove the box from the base. First, open the box and remove the base from the box. Second, remove the contents from the base.
- 3 Remove the Trellis Upright from the box and place on a flat surface, trellis side down. Remove the glass panel and packing material from the Trellis Upright.
- 4 Insert the plumbing into the Trellis Upright, making sure that the arrows are lined up to ensure proper water flow.
- 5 Attach the rubber glass liner to the bottom of the glass panel, then insert the glass panel into the bottom of the upright as shown in Figure A.
- 6 Place the stainless steel distribution panel into place as shown in Figure B. Use Phillips head screws (provided) to attach the distribution panel to the upright with a screwdriver (not included) as shown in Figure C.
- 7 Take the assembled panel with two people and slide the panel into the stainless steel uprights in the base as shown in Figure D. The metal scrollwork should be facing towards the front. Base hole is centered on the back.
- 8 Once the panel is in the base, use the Allen wrench (provided) to tighten the four bolts that are already in the stainless steel supports in the base as shown in Figure E.
- 9 Place the pump in the base. Pull the cord through the hole leaving approximately 12 inches of the cord in the base as shown in Figure F.
- 10 Line up the pump with the plumbing in the base and press together to connect.
- 11 Place the header on top as shown in Figure G.
- 12 Fill the reservoir with water. Do not fill past plughole. Plug in and water should begin to flow. Adjust flow if necessary by turning the black knob located on the delivery tube (base). Water level must be maintained at least one inch above the pump. If water level drops below the top of the pump, damage to the pump may occur.
- 13 Place the FRP trays in the top of the reservoir and arrange the rocks.




Figure A




Figure B



Figure C



Figure D



Figure E



Figure F



Figure G

Thank you for purchasing a Bluworld Water feature. Our artistic designs and superior workmanship bring water features designed for a long-term decorative effect, to produce relaxing sounds and to promote a healing environment. We hope you will enjoy your designer water feature.

Should you experience any problems, please do not return to retailer.

Call 1-888-499-5433 and ask for Customer Service for a quick solution to your problem.

Care and Maintenance

In order to clean the glass, simply remove the header and unscrew the stainless steel distribution panel. Slide the glass panel upwards to remove it from the upright.

Fill the basin with water and plug into a standard electrical outlet. Do not attempt to move the display once it is filled with water. Empty the basin before removing from the wall. Maintain the water level by filling to 2 inches below the top edge of the basin about once a week. Waterfalls that are placed near air conditioning vents and intakes will evaporate at a faster rate. Do not operate if low on water. If hard water is a problem in your area, the use of distilled water will guarantee the best results. It is recommended to drain the reservoir about once every three months and refill with clean water. Be careful not to get cleaning agents into the water. It may be necessary to wipe the inside of the reservoir with a clean cloth to remove any build up.

LIMITED WARRANTY

Bluworld of Water warrants this product to be free from defects in material and workmanship for one (1) year from the original date of purchase by the consumer. This warranty is limited to the replacement of defective parts or components. In addition, the submersible pump is warranted by its manufacturer for a period of one (1) year against defective material and workmanship. All claims must be presented to the manufacturer along with the original purchase receipt to verify a valid warranty period. Bluworld of Water will not be responsible or liable for any damage caused by negligence or misuse, goods damaged in transit, or improper set up, installation or assembly by the purchaser. Bluworld will, upon written notification thereof, take commercially reasonable steps to correct such defects, at Bluworld sole option, by suitable repair, replacement, or refund. Please read all instructions carefully. Notice: Glass mirrors and plastics have prevalent characteristics such as bubbles, mirror rubs, slight discolorations, blurs, and hairline scratches. These are to be expected, as they are inherent qualities that meet or exceed federal specifications DD-G-451D.

bluworld of water

635 W Michigan St. Orlando, FL 32805
407-426-7674 f 407-426-7721 www.bluworldusa.com
2004 Bluworld Innovations LLC, Inc. All Rights Reserved
MADE IN CHINA

Attention

New Warranty in effect as of August 1, 2008

Bluworld's Warranty has changed as of August 1, 2008 and supersedes all previous warranties for product purchased after August 1, 2008. If there is printed material within this shipment it is considered void and the Warranty as stated below is policy.

Bluworld product is warranted against defects that render it unfit for its reasonably intended use. This Warranty is not extended to cover use of the product for a purpose other than as intended, and if the product is used unreasonably, or for purposes other than as intended, or if it is altered, modified or repaired by a party other than Bluworld, then the Warranty shall be null and void. The Warranty is in effect for a period of six months beginning from the date of sale to the original retail purchaser and the rights under this Warranty are limited to the original retail purchaser. Bluworld will, upon written notification thereof, take commercially reasonable steps to correct such defects (see "manufacturers defects below"), at Bluworld's sole option, by suitable repair, replacement, or refund. THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHER WARRANTY OF QUALITY, WHETHER EXPRESS OR IMPLIED, EXCEPT FOR THE WARRANTY OF TITLE AGAINST PATENT INFRINGEMENT. Corrections of nonconformities, in the manner and for the period of time provided above, shall constitute fulfillment of all liabilities of Bluworld to any Dealer with respect to the goods, whether based on contract, negligence, and strict tort or otherwise. Bluworld contract sales personnel, including but not limited to authorized Dealers and Resellers (collectively, "Sales Personnel"), are not authorized to make warranties about Bluworld merchandise. ORAL STATEMENTS DO NOT CONSTITUTE WARRANTIES. Oral statements made by Bluworld employees or other Sales Personnel shall not be relied upon by a Dealer and shall not become part of any contract for sale. The entire sales contract between a Dealer and Bluworld will be set forth in the invoice and/or accompanying or reference documents provided by Bluworld to the Dealer or Sales Personnel. No other warranties are given beyond those set forth in those documents. Please be aware that you may have valuable rights under the state law in which you reside. Some of the provisions of this Warranty may be prohibited by your state law in which case your state law will govern and control. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Our products are warranted for a period of six months against defects in finish, pumps and other product performance issues. Light bulbs are not warranted. Our experience has shown that in practically 100% of incidents that any defect is apparent within a week of installation and use. Appearance defects should be noticed upon unpacking the fountain. We have found that finishes have 'failed' due to poor maintenance, local water conditions with minerals affecting the finish, attempts to clean with harsh chemicals or abrasive pads being used. Performance of water flow, spitting, and other 'leaks', are usually caused by debris getting into the fountain, buildup of minerals, algae from poor water or lack of maintenance. Pumps can also fail due to water levels not being maintained in the reservoir and this is not covered by the warranty.

Manufacturers Defect defined - A distinct and obvious flaw in the manufacturing of the product that inhibits the product's ability to function properly or a distinct and obvious flaw in the workmanship of the product that affects its physical appearance. Bluworld water features are manufactured under generally accepted manufacturing techniques as recognized by the International Organization of Standardization. Our products are hand made and hand finished thus minor scratches in materials within accepted ranges are not considered defects.

Slate- Many of our products contain natural slate. Slate can vary to a large degree and that individuality is what is considered to be unique and inherent to the beauty of the natural product as no two are exactly alike. Photos in our marketing materials are representative of our slate products but should not be relied on to duplicate the photo. We use natural mined slate in our products. Personal taste in the appearance of slate is not considered a reason for a return.

Mirrors-We use tempered mirror in our water features for safety reasons and the process of tempering the mirror may cause the mirrors not to reflect images in the same manner of a non-tempered mirror which is designed to reflect images in their true form. When water is flowing over our tempered mirror surfaces, these slight differences are not noticeable and this is not considered a reason for a return.

Copper- Since we have numerous products manufactured with natural pure copper it is important to note that we do protect the copper with a clear heat-baked on powder coat material. This material should last for a minimum of one year but water conditions may affect the length of protection it will afford to the copper. Copper oxidizes differently than other metals and personal tastes differ as to an individual's perception of it. It may oxidize as a green oxidation or rose colored blush. You can minimize this by wiping down the oxidation and then applying wax or Pledge™ to that area. This condition is not a reason for a return or warranty claim.