

THE **ORIGINAL** BASKETBALL RETURN NET SYSTEM

## **ASSEMBLY INSTRUCTIONS**






Thank you for your purchase of this Rolbak product.

We work around the clock and around the globe to ensure that Rolbak products maintain the highest possible quality. However, in the rare instance that your product is defective or missing parts, contact your retailer to submit parts requests or warranty claims. Please read the warranty information at the back of these assembly instructions for further details.

IMPORTANT! PLEASE READ THESE ASSEMBLY INSTRUCTIONS IN ENTIRETY BEFORE ASSEMBLING YOUR PRODUCT.

# PARTS IDENTIFIER (NOT TO SCALE)





\*\*PLEASE NOTE THAT YOUR BASKETBALL SYSTEM MAY APPEAR DIFFERENTLY THAN THE PICTURED EXAMPLES\*\*

### **WARNINGS!**

READ AND FOLLOW ALL ASSEMBLY, OPERATION, AND SAFETY INSTRUCTIONS CAREFULLY. AT LEAST 2 ADULTS ARE NEEDED FOR THE ASSEMBLY OF THE **ROLBAK NET.** 

NOTE: PORTABLE BASKETBALL HOOPS - ADD EXTRA WEIGHT TO THE PORTABLE SYSTEM'S BASE AS A SAFETY PRECAUTION TO PREVENT YOUR UNIT FROM FALLING OVER, ESPECIALLY IN WINDY CONDITIONS.

DO NOT CLIMB ON THE NET. NEITHER ROLBAK NOR ANY OF ITS REPRESENTA-TIVES, ASSUMES LIABILITY FOR INJURY RESULTING FROM MISUSE OF THE **ROLBAK SYSTEM.** 

FOR AGES 12 AND UP.

## **ASSEMBLY INSTRUCTIONS**





#### PART 1 - ATTACHING THE ROLBAK NET

1. Join the three **Round Silver Tubes** together-swaged ends fit into one another and lock forming one **Assembled Tube**.



2. Slide Assembled Tube through the opening in the top of the Rolbak Net Header.





- **4.** With the **Rolbak Net** now attached to the **Assembled Tube** and **Net Harness**, place **Net Harness** over the basketball hoop rim flush with the backboard.
- **5.** Take the two hanging **Net Harness** straps and thread them through the slits in the **Rolbak Net Header**. Tie these straps behind the backboard to any fixed supports or brackets and tighten firmly. [Note: For adjustable basketball systems, make sure the straps do not restrict the hoop movement or the adjustment mechanism.]




# ASSEMBLY INSTRUCTIONS (CONT.)




### PART 2 - SECURING THE NET BASE


1. Use Paper Funnel to fill the Black Plastic Sand Bag three quarters full. Fasten top with Zip Tie.



2. Insert 2 filled Sand Bags into each Black Mesh Bag.



3. Using Black Mesh Bag's Clips, attach 2 filled Black Mesh Bags to each side of Rolbak Net.






### Congratulations!

You are now ready to use your Rolbak Silver Basketball Return Net System.

#### SUGGESTED USAGE

For Practice: Angle the net forward by pulling base forward.

For Play: Move the net back to the post.



For longer system life, disassemble and store your Rolbak Return Net during winter months.

## **90-DAY LIMITED WARRANTY**



This Rolbak product is warranted to the original purchaser to be free from defects in material or work-manship for a period of ninety days from the date of the original retail purchase.

This warranty does not cover defects or damage due to improper installation, alteration, accident or any other event beyond the control of the manufacturer. Defects or damage resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover scratching or damage that may result from normal usage.

This product is not intended for institutional or commercial use; Rolbak does not assume any liability for such use. Institutional or commercial use will void this warranty.

This warranty is nontransferable and is expressly limited to the repair or replacement of the defective product. During the warranty period, Rolbak shall repair or replace defective parts at no cost to the purchaser. Shipping charges and insurance are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the product or components are not covered under this warranty.

Rolbak reserves the right to make substitutions to warranty claims if parts or unavailable or obsolete.

Rolbak shall not be liable for loss of use of the product or other consequential or incidental costs, expenses or damages incurred by the consumer of any other use. The user assumes all risk of injury resulting from the use of this product.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to the extent permitted by Federal or state law. Neither Rolbak nor any of its representatives assumes any other liability in connection with this product.

All warranty claims must be made through the retailer. A purchase receipt or other proof of date of purchase will be required for all warranty claims. The model number and part numbers will be required when submitting parts requests or warranty claims.

For further warranty information or inquiries, please call 800-759-0977